FITTING INSTRUCTION The instruction of the assembly 1. Disassemble rear light unit. will be not used any more. Clamp mark 5 in acc. with Cables joining ISO PN 4. L Left directional lights Rear fog lights 3 31 Ground Twist bolts M12x1,25x35mm (pos. 5). 4 R Right directional lights 58R Right side parking lights 6 54 Stoplights 6. 58L Left side parking lights 8. Tighten all bolts according to the torque shown in the table. car. (Recommend to make at authorized service station) 3 10. Complete paint layer damaged during installation. 50

This towing hitch is designed to assembly in following cars: KIA PICANTO 3/5 door, produced since 2003, catalogue no. T46 and is prepared to tow trailers max total weight 700 kg and max vertical load 28 kg.

From manufacturer

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towing hitch depends also on correct assembly and right operation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

The towing hitch should be install in points described by a car producer.

- 2. Disassemble rear bumper and metal reinforcement. Metal reinforcement
- Disassemble plastic covers from both sides of the chassis, see fig. 3.
- Put main bar of the towing hitch (pos. 1) to chassis members in this way, so holes of the towing hitch agree with original holes in chassis members.
- 5. Mount cover elements after cut right element according to figure 3.
- Reassemble the bumper after cut his fragments according to figure 2.
- 7. Fix tow ball (pos. 2) using bolt M12x75mm (pos. 4) and M12x70mm (pos. 10). With bolt M12x75mm fix also a socket plate (pos. 3). See figure 1.
- 9. Connect electric wires of 7-pole socket according to the instruction of the

Fig. 2. Bumper cut out

Attention! Cut only right cover.

Fig. 3. Right side cover – cut out.

Cut out

NOTE

After install the towing hitch you should get adequate note in registration book (at authorised service station). The car should be equipped with:

- Indicators ٠
- Tow mirrors

After 1000km of exploitation check all bolts and nuts. The ball of towing hitch must be always kept clear and conserve with a grease.

