

with original holes. Fix loosely couplers (pos. 6 and 7) using bolts M10x35mm (pos. 14). Remember to put washer M14 (pos. 17) between couplers and frame of the car.

After 1000km check all bolts and nuts. The ball of towing hitch must be always kept clear and conserve with a grease.

