	Fitting Fitting TOWBAR DT152U For Nissan Qashqai 2014-	s
×	MATERIALSA1Cross TubeB1Chassis BraceC1Side ArmD1Chassis BraceE1Nut StrapF2M10 x 35 x 1.5 Bolts, Lock Washers and Plain WasherG2M10 x 25 x 1.5 Bolts, Lock Washers and Plain WasherH2M10 x 35 x 1.5 Bolts, Lock Washers and Plain WasherJ1M10 x 35 x 1.5 Bolts, Lock Washers and Plain WasherJ1M10 x 35 x 1.5 Bolts, Lock Washers and Plain WasherK1M10 x 35 x 1.5 Bolts, 2 x Plain Washers and Nyloc NutL1Bumper Foam Support PlateZE1Electrical PlateZN1Neck option	
×	 FITTING Remove the bumper (wheel arch screws, tip screw, 2 bottom edge screws) Remove the bumper beam, and foam block. Remove AdBlue tank, if fitted. (Remove plastic cover, electrical connectors all pipes (self-sealing bayonet connections). Loosely assemble Chassis Brace (B) to <u>inside</u> faces of Left-Hand Chassis rail using fasteners (F). Loosely assemble Chassis Brace (D) to <u>outside</u> faces of Right-Hand Chassis rail using fasteners (G) and Nut Strap (E), which is located by inserting to the inside of the chassis rail. Loosely assemble Side Arm © inside Right-Hand Chassis rail using fasteners (H), through holes in previously fitted Chassis Brace (D). Loosely assemble Side Arm © inside Right-Hand Chassis rail and to Side Arm (C) using fasteners (J, K & L) Tip: Hold Cross Bar (A) into Left Hand Chassis rail and to Side Arm (C) using fasteners (J, K & L) Tip: Hold Cross Bar (A) at 45 degrees (right hand down) while inserting into Left-Hand Chassis rail then rotate antti-clockwise into position. For vehicle bumpers with two large silver panels across the bottom half: Assemble the chosen Neck kit (ZN), and Fixed Electrical Plate (ZE – shown below) to Cross Bar (A) using the respective kit instructions. Cut the bumper swhich have an all-black bottom half: Assemble the chosen Neck kit (ZN), and Retractable Electrical Plate (ZE – included inside Neck Kit) to Cross Bar (A) using the respective kit instructions. Cut the bumper using the 'Bumper Cut 2' image as a guide. For vehicle bumper using the 'Bumper Cut 2' image as a guide. Fully tighten all fasteners Refit the AdBlue tank, if removed in previous instruction. Refit the bumper the foam block to the two studs on the rear panel and then refit the bumper. Recommended torque settings: Grade 8.8 botts: M8 - 24Nm, M10 - 52 Nm, M12 - 80 Nm, M14 - 130 Nm, M16 - 200 Nm <!--</th--><th>5</th>	5
×	Grade 10.9: M12 – 120Nm, M10 – 70Nm M8- 35Nm BUMPER CUT 1 VIEWED FROM REAR OF VEHICLE VIEWED FROM REAR OF VEHICLE	S

