



ΦΑΡΚΟΓΓ.ΡΦ

+7 (495) 669-38-36

NÁVOD NA MONTÁŽ:

Kód: P0415(A,I,C)

- 1. Demontujte 2 skrutky spodných úchytných plastového nárazníka a 4 spodné skrutky M8x25 z kovovej výstuhy nárazníka. ■ 2. Odstráňte plastové kryty z otvorov v spodných stenách pozdĺžnych nosníkov vozidla. ■ 3. Ťažné zariadenie montujte podľa obrázka. Zľahka namontujte konzoly A a B, na ne prichyťte rám C. Skrutkové spoje dotiahnite momentom podľa tabuľky. ■ 4. Namontujte späť spodné držiaky nárazníka. ■ 5. Elektroinštaláciu zapojte podľa návodu. ■ 6. Skontrolujte správnosť pripojenia elektroinštalácie. ■ 7. Skontrolujte dotiahnutie skrutiek spojovacej gule (držiaka spojovacej gule) momentom podľa tabuľky.

FITTING INSTRUCTIONS:

- 1. Remove the 2 screws of the lower holders of the plastic bumper and the 4 lower M8x25 screws from the metal bumper reinforcement. ■ 2. Loosen the bottom plastic covers. ■ 3. Install the tow-bar as shown in the picture. Gently install the brackets A and B, not to snap the frame C. Torque all the screw connections as shown in the table. ■ 4. Replace the lower bumper holders. ■ 5. Connect the electrical installation as described in the instructions for use. ■ 6. Make sure the electrical installation is properly connected. ■ 7. Make sure the screws of the linkage ball (holder of the linkage ball) are torqued as shown in the table.

DŮLEŽITÉ UPOZORNĚNIA:

- V miestach stykových plôch sa musí odstrániť pružná ochrana karosérie vozidla.
- Vŕtané otvory treba ošetriť antikoróznou hmotou.
- Použite len dodaný spojovací materiál v predpisanej triede kvality.
- Elektrické zariadenie sa namontuje podľa podmienok prevádzky cestných vozidiel na pozemných komunikáciách.
- Údaj S o maximálnom zvislom zaťažení na guľu je uvedený na výrobnom štítku ťažného zariadenia.
- Na ťažnom zariadení nie je možné nič upravovať ani meniť.
- Pred ukončením montáže je nutné prekontrolovať všetky spoje podľa tabuľky uťahovacích momentov!
- V prípade akýchkoľvek nejasností je nutné obrátiť sa na výrobcu ťažného zariadenia.
- Výrobca nenesie zodpovednosť za škody spôsobené nesprávnym použitím výrobku.

IMPORTANT ATTENTIONS:

- Remove insulating material on a car body in grips and joints of a coupling device with a car body.
- Put the anticorrosive substance on the drilled holes.
- Use supplied mechanical strength jointing material.
- Wiring of a coupling device must be up to a standard and car maker requirements.
- Statement S about the maximum vertical ball downtake is printed on the tow bar label.
- On the tow bar is no modification possible
- Check all the joints, look in the table of the spining moments, before finishing the montage!
- Contact the tow bar marker with any questions.
- The manufacturer is not responsible for the damages caused by wrong using on the product.

Tabuľka uťahovacích momentov skrutkových spojov pevnosti 8.8 / Table of specified torque and hardness settings 8.8

M6 - 9,5Nm, **M8** - 23Nm, **M10** - 46Nm, **M10x1,25** - 49Nm, **M12** - 79Nm, **M12x1,25** - 87Nm, **M12x1,5** - 83Nm, **M14** - 125Nm, **M16** - 195Nm