



NÁVOD NA MONTÁŽ:

1. Demontujte spodný plastový kryt. Uvoľnite výfuk. 2. Ťažné zariadenie montujte po častiach podľa obrázka. Najprv k pozdĺžnym nosníkom priskrutkujte zľahka postranné konzoly A a B, na ktoré následne prichytíte rám C. Všetky skrutkové spoje následne dotiahnite momentom podľa tabuľky. 3. Elektroinštaláciu zapojte podľa návodu. 4. Skontrolujte správnosť pripojenia elektroinštalácie. 5. Demontujte spojovaciu guľu. 6. Vyrežte vybranie v spodnom plastovom kryte podľa obrázka – DETAIL. 7. Preveďte spätnú montáž demontovaných častí. 8. Namontujte spojovaciu guľu. Dotiahnite skrutky spojovacej guľe (držiačka spojovacej guľe) momentom podľa tabuľky.

FITTING INSTRUCTIONS:

1. Dismount under plastic cover. 2. Install the tow-bar in parts as shown in the picture. First, screw the A and B, side consoles freely onto the longitudinal bars and then join the C frame to these consoles. Torque the screw connections as shown in the table. 3. Connect the electrical installation as described in the instructions for use. 4. Make sure the electrical installation is properly connected. 5. Remove the linkage ball. 6. Cut a cavity in the under plastic cover as shown in the picture – DETAIL. 7. Accomplish re-mounting of all the dismantled parts. 8. Mount the coupling ball. Tighten the bolts and nuts using a torque-wrench to the specified torque.

Kód: T0575(A,I,C)

DŮLEŽITÉ UPOZORNENIA:

- V miestach stykových plôch sa musí odstrániť pružná ochrana karosérie vozidla.
- Vítané otvory treba ošetriť antikoróznou hmotou.
- Použite len dodaný spojovací materiál v predpísanej triede kvality.
- Elektrické zariadenie sa namontuje podľa podmienok prevádzky cestných vozidiel na pozemných komunikáciách.
- Údaj S o maximálnom zvislom zaťažení na guľu je uvedený na výrobnom štítku ťažného zariadenia.
- Na ťažnom zariadení nie je možné nič upravovať ani meniť.
- Pred ukončením montáže je nutné prekontrolovať všetky spoje podľa tabuľky ťahovacích momentov!
- V prípade akýchkoľvek nejasností je nutné obrátiť sa na výrobcu ťažného zariadenia.
- Výrobca nenesie zodpovednosť za škody spôsobené nesprávnym použitím výrobku.

IMPORTANT ATTENTIONS:

- Remove insulating material on a car body in grips and joints of a coupling device with a car body.
- Put the anticorrosive substance on the drilled holes.
- Use supplied mechanical strength jointing material.
- Wiring of a coupling device must be up to a standard and car maker requirements.
- Statement S about the maximum vertical ball downtake is printed on the tow bar label.
- On the tow bar is no modification possible
- Check all the joints, look in the table of the spining moments, before finishing the montage!
- Contact the tow bar marker with any questions.
- The manufacturer is not responsible for the damages caused by wrong using on the product.

Tabuľka ťahovacích momentov skrutkových spojov pevnosti 8.8 / Table of specified torque and hardness settings 8.8

M6 - 9,5Nm, M8 - 23Nm, M10 - 46Nm, M10x1,25 - 49Nm, M12 - 79Nm, M12x1,25 - 87Nm, M12x1,5 - 83Nm, M14 - 125Nm, M16 - 195Nm